

## **IS MY ELEVATOR SAFE??**

## Are <u>ALL</u> of the following statements about your elevator <u>TRUE</u>?

Check Safety Features	TRUE / FALSE
• I cannot open any of the hoistway doors unless the elevator is at	T or F
that floor.	
• If there are any other doors, access panels, windows, or other	T or F
access points to my elevator hoistway, then my elevator is	
automatically disabled if any of those are opened.	
<ul> <li>My elevator has the required working phone.</li> </ul>	T or F
• My elevator's alarm bell rings when the alarm button is pressed.	
My elevator emergency stop button disables the elevator when	T or F
pulled out.	
• My elevator runs only with the gate(s) closed and all the hoistway	T or F
doors closed.	
• If my elevator has a light curtain, my elevator stops when the light	T or F
curtain is obstructed.	



WaupacaElevator.com

<b>Check Installation</b>	TRUE / FALSE
My elevator has been installed and serviced by a factory trained	T or F
technician.	
<ul> <li>My elevator hoistway is fully enclosed.</li> </ul>	T or F
• If my elevator is of the winding drum type, the machine room has a	1 Tor F
lockable entry door.	
• My elevator gate does not allow me to push a three inch diameter	T or F
ball through it anywhere within the gate up to a height of 67	
inches.	
<ul> <li>My elevator is used for a single family residence.</li> </ul>	T or F
• When I stand inside the elevator and open the gate and close the	T or F
hoistway door, I can measure from the surface of the door to the	
center of the gate track and that measurement is 5 inches or less.	
• When I stand inside the elevator and open the gate and close the	T or F
hoistway door, I can measure from the surface of the door to the	
landing edge and that measurement is 3 inches or less.	
• I know where my Owner's Manual is located.	T or F
• I and members of my family have read my Owner's Manual	T or F
entirely and completely understand its contents.	



WaupacaElevator.com

<b>Check Maintenance</b>	TRUE / FALSE
• I have hired someone to maintain my elevator to manufacturer recommended factory specifications.	T or F
• My elevator machine room is clutter free, pest free and well lit.	T or F
<ul> <li>My elevator machine room is free from any drips or puddles of an type.</li> </ul>	y Tor F
<ul> <li>There are no apparent electrical hazards in my elevator machine room.</li> </ul>	T or F
• The equipment in my elevator machine room is rust free.	T or F
<ul> <li>My elevator levels at the floors accurately.</li> </ul>	T or F
<ul> <li>My elevator responds to calls.</li> </ul>	T or F
My elevator cab lights work.	T or F
<ul> <li>My elevator gate is free from defects or broken pieces.</li> </ul>	T or F
<ul> <li>My elevator gate is in good working order and condition.</li> </ul>	T or F
• All of the visible elevator mounting hardware is securely fastened.	TorF
For example the handrail and Interlock.	
<ul> <li>My elevator is free of any unusual noises.</li> </ul>	T or F
<ul> <li>My elevator cab is free from any damage.</li> </ul>	T or F
<ul> <li>My elevator hoistway doors have a working latch set.</li> </ul>	T or F

If <u>ANY</u> of these statements are ever <u>FALSE</u>, or if you still have concerns please call your local residential elevator installation and service company.